

TABLE OF CONTENTS

TITLE	PAGE
INTRODUCTION	3-3
AIRSPEEDS FOR EMERGENCY OPERATIONS.	3-4
ANNUNCIATOR PANEL WARNING LIGHTS.	3-5
ENGINE	3-6
POWER LOSS-DURING TAKEOFF ROLL	3-6
POWER LOSS-AFTER LIFTOFF	3-6
POWER LOSS-IN FLIGHT (RESTART PROCEDURES)	3-6
POWER LOSS-PRIMARY ENGINE INDUCTION AIR SYSTEM BLOCKAGE	3-7
TURBOCHARGER FAILURE	3-8
COMPLETE LOSS OF ENGINE POWER	3-8
PARTIAL LOSS OF ENGINE POWER	3-8
ENGINE POWER OVER BOOST.	3-8
ENGINE ROUGHNESS	3-9
COWL FLAPS FAILURE - FULL CLOSED POSITION	3-9
HIGH CYLINDER HEAD TEMPERATURE	3-9
HIGH OIL TEMPERATURE	3-9
LOW OIL PRESSURE	3-9
LOW FUEL PRESSURE	3-10
ENGINE DRIVEN FUEL PUMP FAILURE	3-10
FUEL VAPOR SUPPRESSION (FLUCTUATING FUEL PRESSURE)	3-10
FIRES	3-10
ENGINE FIRE - DURING START ON GROUND	3-10
ENGINE FIRE - IN FLIGHT.	3-10
ELECTRICAL FIRE - IN FLIGHT (SMOKE IN CABIN)	3-11
EMERGENCY DESCENT PROCEDURE.	3-11
GLIDE	3-11
FORCED LANDING EMERGENCY	3-13
GEAR RETRACTED OR EXTENDED	3-13
OVERWEIGHT LANDING PROCEDURES	3-13
SYSTEMS EMERGENCIES	3-13
PROPELLER.	3-13
FUEL	3-13
ELECTRICAL	3-13
LANDING GEAR.	3-14
VACUUM.	3-15
OXYGEN.	3-15
ALTERNATE STATIC SOURCE	3-15

TABLE OF CONTENTS (con't)

TITLE	PAGE
UNLATCHED DOORS IN FLIGHT	3-15
ICING	3-16
EMERGENCY EXIT OF AIRCRAFT	3-17
SPINS	3-17
OTHER EMERGENCIES	3-18

INTRODUCTION

This section provides the recommended procedures to follow during adverse flight conditions. The information is presented to enable you to form, in advance, a definite plan of action for coping with the most probable emergency situations which could occur in the operation of your airplane.

As it is not possible to have a procedure for all types of emergencies that may occur, it is the pilot's responsibility to use sound judgement based on experience and knowledge of the aircraft to determine the best course of action. Therefore, it is considered mandatory that the pilot read the entire manual, especially this section before flight.

When applicable, emergency procedures associated with optional equipment such as Autopilots are included in SECTION IX.

| NOTE |

All airspeeds in this section are indicated (IAS) and assume zero instrument error unless stated otherwise.

AIRSPEEDS FOR EMERGENCY OPERATIONS

CONDITION RECOMMENDED SPEED

=====

ENGINE FAILURE AFTER TAKEOFF

Wing Flaps UP	85 KIAS
Wing Flaps DOWN	80 KIAS

BEST GLIDE SPEED

3368 lb/1528 kg	91.5 KIAS
3200 lb/1452 kg	89.0 KIAS
2900 lb/1315 kg	84.5 KIAS
2600 lb/1179 kg	80.0 KIAS

MANEUVERING SPEED

3368 lb/1528 kg	127 KIAS
3200 lb/1452 kg	123 KIAS
2900 lb/ 1315 kg	117 KIAS
2600 lb/1179 kg	111 KIAS

PRECAUTIONARY LANDING WITH ENGINE POWER

Flaps DOWN	75 KIAS
----------------------	---------

PRECAUTIONARY LANDING ABOVE 3200 LBS

Flaps DOWN	80 KIAS
----------------------	---------

EMERGENCY DESCENT (GEAR UP)

Smooth Air	195 KIAS
Turbulent Air	
3368 lb/1528 kg	127 KIAS
3200 lb/1452 kg	123 KIAS
2900 lb/1315 kg	117 KIAS
2600 lb/1179 kg	111 KIAS

EMERGENCY DESCENT (GEAR DOWN)

Smooth Air	165 KIAS
Turbulent Air	
3368 lb/1528 kg	127 KIAS
3200 lb/1452 kg	123 KIAS
2900 lb/1315 kg	117 KIAS
2600 lb/1179 kg	111 KIAS

=====

ANNUNCIATOR PANEL WARNING LIGHTS

WARNING LIGHT

FAULT & REMEDY

GEAR UNSAFE

RED light indicates landing gear is not in fully extended/or retracted position. Refer to "FAILURE OF LANDING GEAR TO EXTEND ELECTRICALLY" procedure or "FAILURE OF LANDING GEAR TO RETRACT" procedure.

LEFT or RIGHT FUEL

RED light indicates 2 1/2 to 3 gallons(9.5 to 11.4 liters) of usable fuel remain in the respective tanks. Switch to fuller tank.

SPEED BRAKE

AMBER light indicates Speed Brakes are activated.

ALT AIR

AMBER light indicates alternate induction air door is open.

PROP DE-ICE

BLUE light indicates power applied to De-Ice boots

PITOT HEAT

BLUE light indicates power is applied to heater. (Some Foreign A/C - AMBER light indicates power is NOT applied to heater.)

HI/LO VAC (Flashing)

Suction is below 4.25 in. Hg. (RED)

HI/LO VAC (Steady)

Suction is above 5.5 in. Hg. (RED)

| NOTE |

Attitude and Directional Gyros are unreliable when VAC light is illuminated (steady or flashing). Vacuum system should be checked and/or adjusted as soon as practicable.

ALT VOLTS
(Flashing)

RED light indicates alternator output low. Refer to "ALTERNATOR OUTPUT LOW".

ALT VOLTS
(Steady)

RED light indicates overvoltage and Alt. field. C/B tripped. Refer to "ALTERNATOR OVER-VOLTAGE".

START POWER

RED light indicates switch or relay is engaged and starter is energized. Flight should be terminated as soon as practicable. Engine damage may result. This is normal indication during engine start.

STBY VAC

AMBER light indicates stand-by vacuum pump is ON.

REMOTE RNAV

AMBER light indicates DME not slaved to RNAV.



NOT USED

BOOST PUMP

BLUE light indicates power to auxiliary boost pump.

SECTION III EMERGENCY PROCEDURES

MOONEY
M20M

ENGINE

POWER LOSS - DURING TAKEOFF ROLL

Throttle	CLOSED
Brakes	AS REQUIRED
Fuel Selector	OFF
Magneto/Starter Switch	OFF
Master Switch	OFF

POWER LOSS - AFTER LIFTOFF

Airspeed	85 KIAS (Flaps UP)
	80 KIAS (Flaps TAKEOFF/DOWN)
Keep aircraft under control -		
Fuel selector	SELECT OTHER TANK
Throttle	FULL FORWARD
Fuel Boost Pump	ON to start (Engine driven fuel pump may have failed)
		(Verify fuel pressure is 40 - 50 PSI)
Fuel Boost Pump	OFF if engine does not start immediately
Throttle	RETARD 1 INCH
Propeller	FULL FORWARD
Mixture	FULL FORWARD
Magneto switch	Verify on BOTH

If engine does not restart, proceed to FORCED LANDING EMERGENCY.

POWER LOSS - IN FLIGHT (RESTART PROCEDURES)

Airspeed	85 KIAS minimum
Fuel Selector	SELECT OTHER TANK
Fuel Pressure	Verify in Green Arc
Fuel Boost Pump Switch	ON to start (Engine driven fuel pump may have failed)
Fuel Boost Pump Switch	OFF if engine does not start immediately
Throttle	FULL FORWARD
Propeller	FULL FORWARD
Mixture	FULL FORWARD
Magneto/Starter Switch	VERIFY on BOTH

If engine does not start after initial attempts:

Mixture	IDLE CUT-OFF (Initially)
	then advance slowly toward RICH until engine starts.

If engine does not restart after several attempts establish best glide speed and proceed to FORCED LANDING EMERGENCY.

After engine restart:

Throttle	ADJUST as required
Propeller	ADJUST as required
Mixture	RELEAN as power is restored

LAND AS SOON AS PRACTICABLE; CORRECT MALFUNCTION PRIOR TO NEXT FLIGHT.

~ CAUTION ~

Should the engine excessively cool during engine out, care should be exercised during restart to avoid excessive oil pressure. Allow the engine to warm up.

OPERATING THE ENGINE AT TOO HIGH AN RPM BEFORE REACHING
MINIMUM OIL TEMPERATURES MAY CAUSE LOSS OF OIL PRESSURE.

POWER LOSS - PRIMARY ENGINE INDUCTION AIR SYSTEM BLOCKAGE

Blockage of the primary engine induction air system may be experienced as a result of flying in cloud or heavy snow with cold outside air temperatures (0°C or below). At these temperatures, very small water droplets or solid ice crystals in the air may enter the primary engine induction inlet in cowl opening and travel inside inlet duct to the induction air filter. Ice particles or water droplets may collect and freeze on the air filter causing partial or total blockage of the primary engine induction system.

Indications of primary induction system blockage are either a loss of manifold pressure with a fixed throttle position or the need to gradually advance the throttle to maintain a given manifold pressure setting. In extreme conditions, the loss of indicated manifold pressure and engine power may be quite rapid. A loss of as much as 10 inches Hg. manifold pressure within one minute can be experienced.

If primary induction air system blockage occurs, the alternate engine induction air system will automatically open, supplying engine with an alternate air source drawn from inside the cowl rather than through the air filter. The alternate air system can also be manually opened at any time by pulling the control labeled ALTERNATE AIR. Automatic or manual activation of the alternate induction system is displayed in the cockpit by the illumination of the ALT AIR light in the main annunciator panel. When operating on the alternate air system, available engine power will be less for a given propeller RPM compared to the primary induction air system. This is due to loss of ram effect and induction of warmer inlet air.

The following checklist should be used if a partial power loss due to primary induction air system blockage is experienced:

Engine Power	Verify progressive manifold pressure loss.
Alternate Air	Verify OPEN (annunciator light ON)

| NOTE |

The alternate air door should open automatically when primary induction system is restricted. If alternate air door has not opened (Annunciator light-OFF) it can be opened manually by pulling alternate air control.

Throttle	.	.	.	INCREASE to maintain desired manifold pressure
Propeller	.	.	.	INCREASE as required
	.	.	.	to maintain desired cruise power setting (Ref. SECTION V)
Mixture	.	.	.	RELEASE to PEAK TIT

NOTE

Approximately 81% power can be maintained at 20,000 ft. with the primary induction system totally blocked, alternate air door open, full throttle, 2400 RPM and leaned to peak TIT.

Flight	CONTINUE
--------	---	---	---	---	----------

In the unlikely event that a total power loss due to primary engine induction air blockage is experienced, the following checklist should be used:

Airspeed	85 KIAS
Alternate Air	Manually OPEN
Throttle	Full FORWARD
Fuel Boost Pump	Verify ON
Propeller	FULL FORWARD
Mixture	IDLE CUTOFF initially
	then advance toward RICH to attempt engine restart
Magneto/Starter Switch	Verify on BOTH

SECTION III EMERGENCY PROCEDURES

MOONEY
M20M

After engine restart:

Throttle	ADJUST as required
Propeller	ADJUST as required
Mixture	RELEASE as power is restored
	(Refer to power charts - SECTION V)
Fuel Boost Pump	Verify OFF

If engine does not restart after several attempts, proceed to FORCED LANDING EMERGENCY.

TURBOCHARGER FAILURE

////////////////////
// WARNING //
////////////////////

If a turbocharger failure is a result of a loose, disconnected or burned through exhaust, then a serious fire hazard exists. If a failure in the exhaust system is suspected in flight, shut down the engine and LAND AS SOON AS POSSIBLE. If a suspected exhaust system failure occurs before takeoff, DO NOT FLY THE AIRCRAFT.

| NOTE |

A turbocharger malfunction at altitudes above 12,000 ft. could result in a overly rich mixture which could cause a partial power loss and rough running engine or a complete loss of engine power.

COMPLETE LOSS OF ENGINE POWER

If a suspected turbocharger or turbocharger waste gate control system failure results in a complete loss of engine power, the following procedure is recommended:

Mixture	IDLE CUTOFF
Throttle	CRUISE
Propeller	FULL FORWARD
Mixture	ADVANCE slowly until engine re-starts
Continue Flight	LAND AS SOON AS POSSIBLE

PARTIAL LOSS OF ENGINE POWER

If turbocharger wastegate control fails in the OPEN position, a partial loss of engine power may result. The following procedure is recommended if a suspected turbocharger/wastegate control failure results in a partial loss of engine power:

Throttle	AS REQUIRED
Propeller	AS REQUIRED
Mixture	AS REQUIRED
Continue Flight	LAND AS SOON AS POSSIBLE

ENGINE POWER OVERBOOST

If the turbocharger wastegate control fails in the CLOSED position, an engine power overboost condition may be experienced. The following procedure is recommended for an overboost condition:

Throttle	REDUCE as necessary to keep manifold pressure within limits
--------------------	---

NOTE

Expect manifold pressure response to throttle movements to be sensitive.

Propeller	AS REQUIRED
Mixture	AS REQUIRED
Continue Flight	LAND AS SOON AS POSSIBLE

ENGINE ROUGHNESS

Engine Instruments	CHECK
Fuel Selector	OTHER TANK
Mixture	READJUST for smooth operation
Magneto/Starter Switch	Select R or L or BOTH

If roughness disappears on single magneto, monitor power and continue on selected magneto.

//////////
//WARNING//
//////////

The engine may quit completely when one magneto is switched off if the other magneto is faulty. If this happens, close throttle to idle and mixture to idle cutoff before turning magnetos ON to prevent a severe backfire. When magnetos have been turned back ON, proceed to POWER LOSS - IN FLIGHT. Severe roughness may be sufficient to cause propeller separation. Do not continue to operate a rough engine unless there is no other alternative.

Throttle	REDUCE
check for a throttle setting that may cause roughness to decrease.	
If severe engine roughness cannot be eliminated, LAND AS SOON AS PRACTICABLE.	

COWL FLAPS FAILURE - FULL CLOSED POSITION

Acceptable engine operating temperatures can always be maintained in flight if cowl flaps fail in the full closed position using the following procedure:

Power	AS REQUIRED
Mixture	RICH
Airspeed	140 KIAS in Climb
Cylinder Head & Oil Temperature	MONITOR - normal operating range

HIGH CYLINDER HEAD TEMPERATURE

Mixture	ENRICH As Required
Cowl Flaps	OPEN as Required
Airspeed	INCREASE As Required
Power	REDUCE — if temperature cannot be maintained within limits

HIGH OIL TEMPERATURE

| NOTE |

Prolonged high oil temperature indications will usually be accompanied by a drop in oil pressure. If oil pressure remains normal, then a high temperature indication may be caused by a faulty gauge or thermocouple.

Cowl Flaps	OPEN as required
Airspeed	INCREASE
Power	REDUCE

PREPARE FOR POSSIBLE ENGINE FAILURE IF TEMPERATURE CONTINUES HIGH.

LOW OIL PRESSURE

Oil temperature and pressure gauges	Monitor
Pressure below 25 PSI	EXPECT ENGINE FAILURE,
proceed to FORCED LANDING EMERGENCY.	

SECTION III EMERGENCY PROCEDURES

MOONEY
M20M

LOW FUEL PRESSURE

Fuel Boost Pump	ON
Throttle	REDUCE to 34 In. or below
Fuel Pressure	MONITOR
Fuel Boost Pump	OFF
If condition persists:	
Fuel Boost Pump	ON
Repeat above procedures until Fuel Pressure stabilizes.	
LAND AS SOON AS PRACTICABLE	

ENGINE DRIVEN FUEL PUMP FAILURE

An engine driven fuel pump failure is probable when low fuel pressure is indicated and when the engine will only operate with boost pump ON. Operation of the engine with a failed engine driven fuel pump and the BOOST PUMP ON will require smooth operation of engine controls and corresponding mixture change when throttle is repositioned or engine speed is changed. Always lean to obtain a smooth running engine.

The following procedure should be followed when a failed engine driven fuel pump is suspected:

Fuel Boost Pump	ON
Throttle	CRUISE Position
Mixture	ADJUST for smooth engine operation.
LAND AS SOON AS PRACTICABLE.	

FUEL VAPOR SUPPRESSION (Fluctuating Fuel Pressure)

Fuel Boost Pump	ON
Fuel Pressure	MONITOR
Fuel Boost Pump	OFF - (If condition still exists, REPEAT PROCEDURE).

FIRES

ENGINE FIRE-DURING START ON GROUND

Magneto/Starter Switch	CONTINUE cranking or until fire is extinguished.
If engine starts:	
Power	1500 RPM for several minutes
Engine	SHUTDOWN; inspect for damage
If engine does NOT start:	
Magneto/Starter Switch	CONTINUE CRANKING
Mixture	IDLE CUTOFF
Throttle	FULL FORWARD
Fuel Selector Valve	OFF
Magneto/Starter Switch	OFF
Master Switch	OFF
Fire	EXTINGUISH with Fire Extinguisher

ENGINE FIRE - IN FLIGHT

Fuel Selector Valve	OFF
Throttle	CLOSED
Mixture	IDLE CUTOFF
Magneto/Starter Switch	OFF
Cabin Ventilation & Heating Controls	CLOSED
Cowl Flaps	CLOSED

NOTE

If fire is not extinguished, attempt to increase airflow over the engine by increasing glide speed. Proceed with FORCED LANDING EMERGENCY. DO NOT attempt an engine restart.

ELECTRICAL FIRE-IN FLIGHT (Smoke in Cabin)

Master Switch OFF

/////////////////
//WARNING//
/////////////////

Stall warning and landing gear warning are not available with Master Switch OFF.

Alternator Field Switches	OFF
Cabin Ventilation	OPEN
Heating Controls	CLOSED
Circuit Breakers	CHECK to identify faulty circuit if possible

LAND AS SOON AS POSSIBLE.

If electrical power is essential for flight, attempt to identify and isolate faulty circuit as follows:

Master Switch	ON
L & R Alternator Field Switches	ON

Select ESSENTIAL switches ON one at a time; permit a short time to elapse before activating an additional circuit.

EMERGENCY DESCENT PROCEDURE

In the event an emergency descent from high altitude is required, rates of descent of at least 3,000 feet per minute can be obtained in two different configurations:

(1) With landing gear and flaps retracted, an air speed of 195 KIAS will be required for maximum rate of descent.

(2) With the landing gear extended and flaps retracted an airspeed of 165 KIAS will also give approximately the same rate of descent. At 165 KIAS and the gear extended, the angle of descent will be greater, thus resulting in less horizontal distance traveled than a descent at 195 KIAS. Additionally, descent at 165 KIAS will provide a smoother ride and less pilot work load.

THEREFORE; The following procedure is recommended for an emergency descent:

Power	RETARD INITIALLY
Airspeed	140 KIAS
Landing Gear	EXTEND
Airspeed	INCREASE TO 165 KIAS after landing gear is extended.
Wing Flaps	UP
Cowl Flaps	CLOSED
Airspeed	MAINTAIN 165 KIAS during descent.
Speedbrakes (If installed)	EXTEND
Altitude	AS DESIRED

~CAUTION~


Do not exceed 20" Hg. Manifold Pressure before CHT is above 250°F (121°C).

SECTION III
EMERGENCY PROCEDURES

MOONEY
M20M

GLIDE

MAXIMUM GLIDE DISTANCE - MODEL M20M



| NOTE |

Greater glide distances can be attained by moving the propeller control FULL AFT (LOW RPM).

FORCED LANDING EMERGENCY

GEAR RETRACTED OR EXTENDED

Emergency Locator Transmitter	ARMED
Seat Belts/Shoulder Harnesses	SECURE
Cabin Door	UNLATCHED
Fuel Selector Valve	OFF
Mixture	IDLE CUTOFF
Magneto/Starter Switch	OFF
Wing Flaps	Full DOWN
Landing Gear	DOWN-If conditions permit
Approach Speed	80 KIAS
Master Switch	OFF, prior to landing
Wings	LEVEL Attitude

OVERWEIGHT LANDING PROCEDURES

In the event it is necessary to land with a weight exceeding 3200 Lbs. (1452 Kg.) (max. landing weight) the following procedure is recommended in addition to normal APPROACH FOR LANDING procedures:

Approach Airspeed 80 KIAS

Use a flatter approach angle than normal, with power as necessary until a smooth touch down is assured.

Expect landing distance over a 50 foot obstacle (Ref. SECTION V) to increase at least 600 ft. Conduct Gear and Tire Servicing inspection as required (Ref. SECTION VIII).

SYSTEMS EMERGENCIES

PROPELLER

PROPELLER OVERSPEED

Throttle	RETARD
Oil Pressure	CHECK
Propeller	DECREASE RPM if any control available
Airspeed	REDUCE
Throttle	AS REQUIRED to maintain RPM below 2575 RPM

FUEL

LOW FUEL FLOW

Check mixture	ENRICH
Fuel Selector	SWITCH TANKS

If condition persists, use Fuel Boost Pump as necessary. LANDING should be made as soon as PRACTICABLE.

ELECTRICAL

ALTERNATOR OVERVOLTAGE/ FAILURE

(Alternator warning light illuminated steady. The Alternator Field circuit breaker may be tripped (overvoltage) or it may remain in its normal position (field fault).

Alternator Field Circuit Breaker	RESET (if tripped)
--	--------------------

If circuit breaker will not reset, the following procedures are required:

1. Monitor ammeter for discharge
2. Reduce electrical load, as required, to maintain a positive ammeter indication and operate within the load capacity of remaining alternator.

NOTE: (S/N 27-0317 THRU 27-TBA) Activating the EMERG BUS switch will automatically shed all systems outside the Yellow "ESSENTIAL" bands located on the Circuit Breaker Panel. All systems located within the Yellow "ESSENTIAL" bands will remain powered by the remaining alternator, or in the case of Dual alternator failure, the selected battery.

3. Continue flight on remaining alternator and LAND, when PRACTICABLE, to correct malfunction.

ALTERNATOR OUTPUT LOW (Alternator warning light flashing)

Reduce Electrical Load	Turn Switches OFF
----------------------------------	-------------------

If annunciator light still flashes:

Affected alternator Field Switch.	OFF
---	-----

1. Monitor ammeter for discharge.
2. Reduce electrical load, as required, to maintain positive ammeter indication and operate within the load capacity of remaining alternator.

SECTION III EMERGENCY PROCEDURES

MOONEY
M20M

NOTE: (S/N 27-0317 THRU 27-TBA) Activating the EMERG BUS switch will automatically shed all systems outside the Yellow "ESSENTIAL" bands located on the Circuit Breaker Panel. All systems located within the Yellow "ESSENTIAL" bands will remain powered by the remaining alternator, or in the case of Dual alternator failure, the selected battery.

3. Continue flight on remaining alternator and LAND, when PRACTICABLE, to correct malfunction.

DUAL ALTERNATOR FAILURE (Ammeter indicates discharge)

If alternator will not reset:

On S/N 27-0001 THRU 27-0316

Non-essential electrical equipment OFF to conserve battery power

On S/N 27-0317 THRU 27-TBA

EMERG BUS ON to conserve battery power

LAND AS SOON AS PRACTICABLE

Battery endurance will depend upon battery condition and electrical load on battery. If one battery becomes depleted, switch to other battery.

LANDING GEAR

FAILURE OF LANDING GEAR TO EXTEND ELECTRICALLY

Airspeed	140 KIAS or less
Landing Gear Actuator Circuit Breaker	PULL
Landing Gear Switch	DOWN
Manual Gear Extension Mechanism	LATCH FORWARD/LEVER BACK to engage manual extension mechanism

NOTE

Slowly pull "T" handle 1 to 2 inches (2.5 to 5.1 cm) to rotate clutch mechanism and allow it to engage drive shaft.

T-Handle	PULL (12 to 20 times) and RETURN until gear is down and locked
	GEAR DOWN light ILLUMINATED; STOP when resistance is felt.
Visual Gear Down Indicator	CHECK ALIGNMENT by viewing from directly above indicator

~ CAUTION ~

Continuing to pull on T-Handle, after GEAR DOWN light ILLUMINATES, may bind actuator; electrical retraction MAY NOT be possible until binding is eliminated by ground maintenance. Return lever to normal position and secure with latch. Reset landing gear actuator circuit breaker.

/////////////////
//WARNING//
/////////////////

Do not operate landing gear electrically with manual extension system engaged

FAILURE OF LANDING GEAR TO RETRACT

AIRSPEED	Below 107 KIAS
GEAR Switch	UP Position
GEAR FAILS TO RETRACT	
GEAR HORN - SOUNDING;	
GEAR ANNUNCIATOR LIGHT & GEAR SAFETY BY-PASS LIGHT - ILLUMINATED	
GEAR SAFETY BY-PASS SWITCH	DEPRESS
	HOLD until landing gear is fully retracted
"GEAR UNSAFE" and "GEAR DOWN" Lights.	EXTINGUISHED
"GEAR RELAYS" Ckt. Bkr	PULL
	(Warning Horn and Gear By Pass light will go OFF)

Check "Airspeed Safety Switch" or other malfunction as soon as practicable.
"GEAR RELAYS" Ckt. Bkr.

PUSH IN

GEAR FAILS TO RETRACT
GEAR HORN - DOES NOT SOUND
GEAR ANNUNCIATOR LIGHTS & GEAR BY-PASS LIGHT - NOT ILLUMINATED

EMERGENCY GEAR EXTENSION LEVER Verify LATCHED in proper position
GEAR RELAYS C/B RESET
FLIGHT CONTINUE (if desired)

When ready to extend landing gear:

AIRSPPEED Below 140KIAS
GEAR RELAYS C/B RESET
GEAR SWITCH DOWN Position

If gear will not extend electrically, refer to FAILURE OF LANDING GEAR TO EXTEND ELECTRICALLY.

| NOTE |

If above procedures do not initiate retraction process, check emergency manual extension lever on floor for proper position.

VACUUM

When "HI/LO VAC" annunciator light illuminates (flashing or steady), vacuum operated instruments are considered to be unreliable. Push stand-by vacuum pump switch ON. The FLASHING HI/LO VAC annunciator light should extinguish and the STBY VAC annunciator will illuminate. The vacuum operated gyro instruments will be operating on the stand-by vacuum system. The STEADY RED annunciator light may not extinguish when the Stand-by Vacuum Switch is ON. Continue flight and have Vacuum System inspected prior to next flight.

OXYGEN

In the event of oxygen loss above 20,000 ft. refer to "EMERGENCY DESCENT PROCEDURE" to safely & quickly get to 12,500 ft. or below.
Refer to SECTION X for the physiological characteristics of high altitude flight.

ALTERNATE STATIC SOURCE

The alternate static air source should be used whenever it is suspected that the normal static air sources are blocked. Selecting the alternate static source changes the source of static air for the altimeter, airspeed indicator and rate-of-climb from outside of the aircraft to the cabin interior.

When alternate static source is in use, adjust indicated airspeed and altimeter readings according to the appropriate alternate static source airspeed and altimeter calibration tables in SECTION V.
The alternate static air source valve is located on the instrument panel below pilot's control wheel.

| NOTE |

When using the Alternate Static Source the pilot's window and air vents MUST BE KEPT CLOSED.

Alternate Static Source PULL ON
Airspeed and Altimeter Readings CHECK Calibration Tables (Ref SECTION V)

UNLATCHED DOORS IN FLIGHT

CABIN DOOR

If cabin door is not properly closed it may come unlatched in flight. This may occur during or just after take-off. The door will trail in a position approximately 3 inches (7.6 cm) open, but the flight characteristics of the airplane will not be affected. Return to the field in a normal manner. If possible, secure the door in some manner to prevent it from swinging open during the landing.

SECTION III EMERGENCY PROCEDURES

MOONEY
M20M

If it is deemed impractical to return and land, the door can be closed in flight, after reaching a safe altitude, by the following procedures:

Airspeed	95 KIAS
Pilot's Storm Window	OPEN
Aircraft	RIGHT SIDESLIP (Right bank with left rudder)
Door	PULL SHUT & LATCH

BAGGAGE DOOR

If baggage door is not properly closed, it may come unlatched in flight. This may occur during or after take off. The door may open to its full open position and then take an intermediate position depending upon speed of aircraft. There will be considerable wind noise; loose objects, in the vicinity of the open door, may exit the aircraft. There is no way to shut and latch the door from the inside; fly aircraft in normal manner; LAND AS SOON AS POSSIBLE and secure the baggage door.

Baggage Door latching mechanism VERIFY PROPERLY ENGAGED
(inside latching mechanism) then shut from outside.

ICING

////////////////////
//WARNING//
////////////////////

DO NOT OPERATE IN KNOWN ICING CONDITIONS.

The Model M20M is NOT APPROVED for flight into known icing conditions and operation in that environment is prohibited. However, if those conditions are inadvertently encountered or flight into heavy snow is unavoidable, the following procedures are recommended until further icing conditions can be avoided:

INADVERTENT ICING ENCOUNTER

Pitot Heat	ON
Propeller De-ice	ON (if installed)
Alternate Static Source	ON (if required)
Cabin Heat & Defroster	ON
Manifold Pressure Gauge	MONITOR for any engine power reduction

Turn back or change altitude to obtain an outside air temperature less conducive to icing.

Move propeller control to maximum RPM to minimize ice build-up on propeller blades. If ice builds up or sheds unevenly on propeller, vibration will occur. If excessive vibration is noted, momentarily reduce engine speed with propeller control to bottom of GREEN ARC, then rapidly move control FULL FORWARD.

| NOTE |

Cycling RPM flexes propeller blades and high RPM increases centrifugal force which improves propeller capability to shed ice.

As ice builds on the airframe, move elevator control fore and aft slightly to break any ice build-up that may have bridged gap between elevator horn and horizontal stabilizer.

Watch for signs of induction air filter blockage due to ice build-up; increase throttle setting to maintain manifold pressure.

| NOTE |

If ice blocks induction air filter, alternate air system will open automatically.

With ice accumulation of 1/4 inch or more on the airframe, be prepared for a significant increase in aircraft weight and drag. This will result in significantly reduced cruise and climb performance and higher stall speeds. Plan for higher approach speeds requiring higher power settings and longer landing rolls.

~ CAUTION ~

Stall warning system may be inoperative.

The de froster may not clear ice from wind shield. If necessary open pilot's storm window for visibility in landing approach and touchdown.

With ice accumulations of 1 inch or less, use no more than 15° wing flaps for approach and landing. For ice accumulation of 1 inch or more, fly approaches and landing with flaps retracted to maintain better pitch control. Fly approach speed at least 15 knots faster than normal, expect a higher stall speed resulting in higher touchdown speed with longer landing roll. Use normal flare and touchdown technique.

Missed approaches SHOULD BE AVOIDED whenever possible because of severely reduced climb performance. If a go-around is mandatory, apply full power, retract landing gear when obstacles are cleared; maintain 90 KIAS and retract wing flaps.

— AVOID FURTHER ICING CONDITIONS —

EMERGENCY EXIT OF AIRCRAFT

CABIN DOOR

PULL latch handle AFT.
OPEN door and exit aircraft.

BAGGAGE COMPARTMENT DOOR (Auxiliary Exit)

Release (Pull UP) rear seat back latches on spar.
Fold rear seat backs forward, CLIMB OVER.
PULL off plastic cover.
PULL latch pin.
Lift red handle "UP".
OPEN door and exit aircraft.

To VERIFY RE-ENGAGEMENT of baggage door, outside, latch mechanism:

Open outside handle fully.
Close inside RED handle to engage pin into cam slide of latch mechanism.
Place latch pin in shaft hole to hold RED handle DOWN.
Replace cover.
CHECK & operate outside handle in normal manner.

SPINS

//////
//WARNING//
//////

Up to 2,000 ft. altitude may be lost in a one turn spin and recovery;
STALLS AT LOW ALTITUDE ARE EXTREMELY CRITICAL.

| NOTE |

The best spin avoidance technique is to avoid flight conditions conducive to spin entry. Low speed flight near stall should be approached with caution and excessive flight control movements in this flight regime should be avoided. Should an unintentional stall occur, the aircraft should not be allowed to progress into a deep stall. Fast, but smooth stall recovery will minimize the risk of progressing into a spin. If an unusual post stall attitude develops and results in a spin, quick application of antispin procedures should shorten the recovery.

INTENTIONAL SPINS ARE PROHIBITED.

In the event of an inadvertent spin, the following recovery procedure should be used:

Throttle	RETARD to IDLE
Ailerons	NEUTRAL
Rudder.	Apply FULL RUDDER opposite direction of spin
Control Wheel	FORWARD of neutral in a brisk motion

ADDITIONAL FORWARD elevator control may be required if rotation does not stop.

— HOLD ANTI-SPIN CONTROLS UNTIL ROTATION STOPS —

Wing Flaps (If extended)	RETRACT as soon as possible
Rudder	NEUTRALIZE when spin stops
Control Wheel	SMOOTHLY MOVE AFT
					to bring the nose up to level flight attitude.

OTHER EMERGENCIES

Refer to SECTION IX for Emergency Procedures of Optional Equipment.